


Tuyau de chargement mobile



TUYAU CHARGEMENT
MOBILE



TUYAU CHARGEMENT MOBILE
HYDRAULIQUE (OPTION)


Livre de pièce

0901LPT

Table des matières

Tuyau chargement mobile


Tuyau chargement mobile.....	PAGE 3 & 4
Tuyau chargement mobile hydraulique (option).	PAGE 5 & 6
Dessin Hydraulique.....	PAGE 7



TUYAU CHARGEMENT

NO.	NUMERO	PIECE	NO.	NUMERO	PIECE
1	LPT-S001	Chassis	16	PM-P702	Valve
2	PM-S024	Roue	17	PM-P329	Spring
3	PM-P642	Pin	18	LPT-S013	Pin
4	PM-P392	Goupille fendu	19	PM-P690	Vis auto-percante Ø1-4 x 1 1-2
5	LPT-P063	Essieu	20	B50,37NC1,25	Boulon - 3/8-16x1 1/4
6	LPT-P002A	Tube	21	NL50,37NC	Écrou auto-blocant 3-8 UNC
7	B50,62NC4	Boulon - 5/8-11x4	22	WL0,25	Rondelle blocante - 1/4
8	W0,625	Rondelle - 5/8	23	LPT-S006	Tuyau
9	NL50,62NC	Écrou auto-blocante 5-8 UNC	24	LPT-S009	Pin
10	LPT-S005	Pivot	25	LPT-S015	Panier
11	LPT-S002	Bras	26	LPT-P064	Tuyau caoutchouc
12	LPT-S011	Pin	27	B50,5NC8,5	Boulon - 1/2-13x8 1/2
13	PM-S023	Moyeu roue	28	HYD-P052	Graisneur
14	LPT-S014	Plaque	29	NL50,5NC	Écrou auto-blocant 1-2 UNC
15	PM-P701	Treuil			


TUYAU CHARGEMENT MOBILE HYDRAULIQUE (option)



TUYAU CHARGEMENT MOBILE **HYDRAULIQUE (option)**

NO.	NUMERO	PIECE	NO.	NUMERO	PIECE
1	LPT-S017	Chassis	13	PM-P690	Vis auto-percante Ø1-4 x 1 1-2
2	PM-S024	Roue	14	PM-P702	Valve
3	PM-P392	Goupille fendu	15	PM-P642	Pin
4	PM-P510	Cylindre	16	PM-S023	Moyeu roue
5	LPT-P063	Essieu	18	LPT-S013	Pin
6	LPT-P002A	Tube	23	LPT-S006	Tuyau
7	B50,62NC4	Boulon - 5/8-11x4	24	LPT-S009	Pin
8	W0,62	Rondelle - 5/8	25	LPT-S015	Panier
9	NL50,62NC	Écrou auto-blocant 5-8 UNC	26	LPT-P064	Tuyau caoutchouc
10	LPT-S018	Pivot	28	HYD-P052	Graisser
11	WL0,25	Rondelle blocante - 1/4	30	PM-P026	Pin
12	LPT-S011	Pin	31	LPT-S003	Tube cylindre

SHÉMA HYDRAULIQUE



NO.	NUMERO	PIECE	NO.	NUMERO	PIECE
1	HYD-P007	HYD. CONNECTEUR RAPIDE	10	LPT-P071	HYD. TUYAU LONG
2	HYD-P022	HYD. COUDE 90°	11	LPT-P072	HYD. TUYAU COURT
3	PM-P510	CYLINDRE			